

Wedgegard® Chain Coupling Manual Reset

DATASHEET Version 4/2020

Torque Table / Nm



Model	S350		S500		S700		S950		S1000
WEDGEPIN	W37		W50		W50		W100		W100
Brass = B / STEEL = S	B	S	B	S	B	S	B	S	S
TORQUE CODES	* Wedgepins x 3		* Wedgepins x 3		* Wedgepins x 3		* Wedgepins x 3		* Wedgepins x 4
O	45	62	52	71	126	173	-	-	-
OW	62	85	72	99	191	274	-	-	-
GD	84	115	97	134	-	-	-	-	-
W	116	159	135	185	275	377	830	1140	3470
WY	167	230	194	266	373	512	1165	1600	5160
Y	221	303	256	352	487	705	1475	2030	6940
YB	293	402	340	467	712	978	2010	2760	8720
BN	303	-	352	-	-	-	-	-	-
B	345	474	400	549	978	1344	2400	3300	9820
BG	402	552	467	640	1222	1678	2850	3900	11610
G	497	682	576	791	1494	2050	3600	4900	13880
RG	601	825	697	957	1886	2589	4200	5700	-
R	676	928	784	1076	1950	2678	4800	6600	15980
RK	-	-	-	-	-	-	-	-	-
K	-	-	-	-	2032	2791	5600	7650	16920

* Full complement or single pin can be used.


Torque figures are for single Wedgepin fitted – adjust torques by adding Wedgepins or fitting multiple codes.

Ordering new Wedgepins

Example: W37 - B - R

W37 Wedgepin size	B Material Brass	R Breaking Torque Code Letter
-----------------------------	----------------------------	---

Identification on existing Wedgepin



Tel: +44 (0)1453 750814
 Fax: +44 (0)1453 765320
www.howdon.co.uk
sales@howdon.co.uk

