

Wedgegard® Type NFS Flexible Coupling

Torque Table / ft-lbs



DATASHEET Version 4/2020

Model	NFS350 – 110		NFS500 – 125		NFS700 – 180		NFS700 – 225		NFS950 – 250	
WEDGE PIN	W37		W37		W50		W50		W75	
Brass = B / STEEL = S	B	S	B	S	B	S	B	S	B	S
TORQUE CODES	* Wedgepins x 3		* Wedgepins x 3		* Wedgepins x 3		* Wedgepins x 3		* Wedgepins x 3	
O	33	45	38	52	93	128	93	128	-	-
OW	46	63	53	73	141	202	141	202	-	-
GD	62	85	72	99	-	-	-	-	-	-
W	86	118	100	136	203	278	203	278	612	841
WY	123	170	143	196	275	378	275	378	859	1180
Y	163	224	189	260	359	520	359	520	1088	1497
YB	216	297	251	344	525	722	525	722	1482	2036
BN	223	-	260	-	-	-	-	-	-	-
B	254	349	295	405	722	991	722	991	1770	2434
BG	297	407	344	472	901	1238	901	1238	2102	2876
G	366	503	425	583	1102	1512	1102	1512	2655	3614
RG	443	609	514	706	1391	1910	1391	1910	3098	4204
R	498	685	578	794	1438	1975	1438	1975	3540	4868
RK	-	-	-	-	-	-	-	-	-	-
K	-	-	-	-	1499	2058	1499	2058	4130	5642


* Full complement or single pin can be used.

Torque figures are for single Wedgepin fitted – adjust torques by adding Wedgepins or fitting multiple codes.

Ordering new Wedgepins
Example: W37 - B - R

W37 Wedgepin size	B Material Brass	R Breaking Torque Code Letter
-----------------------------	----------------------------	---

Identification on existing Wedgepin



Tel: +44 (0)1453 750814
Fax: +44 (0)1453 765320
www.howdon.co.uk
sales@howdon.co.uk

